

How to connect with Bluetooth

Note:

1. The most reliable audio connection is via cable
2. You need to stay in Bluetooth range.
3. Large numbers of devices in the room can be disruptive.

(1) Press this button to enable Bluetooth

- The blue light will then flash
- Connect to WP225
- Adjust volume from your device.

(2) Input should be 'HDMI 1'



(3) Sound output should be 'Audio ST'

(4) Control relative volume using this dial

How to connect to the AV system using cable

Note:

1. If your device does not have a 3.5mm cable output use:

1. Lightning to 3.5mm convertor
2. USB-C to 3.5mm convertor

(1) Insert a 3.5mm jack plug into this socket.

- Adjust volume from your device.

(2) Input should be 'HDMI 1'



(2) Sound output should be 'Audio ST'

(3) Control relative volume using this dial

How to connect to the projector

Note:

1. The HDMI input uses our 2 channel stereo system so that you can have concurrent BlueTooth and microphone audio

(1) Press **and hold** for 5 seconds the 'Proj on' button

(2) Press the HDMI button

(3) Connect to the projector using this HDMI socket

(4) Press 2 channel stereo button

(5) Check cupboard doors are closed and then Press Screen Down button

(6) Control HDMI volume relative to other inputs using this dial



How to use the Blu-ray / media player

Note:

1. You will need to arrange access to the media cupboard key to load a Blu-ray and obtain the Panasonic remote control.

(1) Press **and hold** for 5 seconds the 'Proj on' button.

(2) Press **t and hold** the Blu-ray button

(6) Point the Panasonic remote control at this plate to control the player



(4) Control volume using this dial

(5) Check cupboard doors are closed and then Press 'Screen Down' button

How to use the Apple TV player

Note:

1. You will need to arrange access to the media cupboard key obtain the Apple TV remote control.

(1) Press **and hold** for 5 seconds the 'Proj on' button.

(2) Press **and hold** the Apple TV button

(6) Point the Apple TV remote control at this plate to control the player



(4) Control volume using this dial

(5) Check cupboard doors are closed and then Press 'Screen Down' button

Trouble shooting...



Problem	Check
No sound	The input is not muted (small button)
	For Bluetooth, HDMI and Microphones press Audio ST button
	For Bluetooth forget device on your phone and restart connection